

FIG.24




FIG.25

```
-- ACQUISITION OF ADDRESS
IF INI_CNT < MAX
    -- ACQUIRED FROM ADDRESS GENERATION COUNTER
    INI_CNT ++
    W_ADR = INT_CNT
ELSE
    -- ACQUIRED FROM FREE ADDRESS FIFO
    W_ADR = EMP_S_PNT
    EMP_S_PNT = LINK(EMP_S_PNT)
ENDIF
-- UPDATING OF POINTER LINK
IF CNT_L(BUF) = 0
    -- PROCESSING WHEN CELL BUFFER IS FREE
    S_PNT(BUF) = W_ADR
    E_PNT(BUF) = W_ADR
ELSE
    -- PROCESSING WHEN CELL BUFFER IS NOT FREE
    LINK(E_PNT(BUF)) = W_ADR
    E_PNT(BUF) = W_ADR
ENDIF
-- UPDATING OF COUNTER
CNT_L(BUF) ++
CNT_S(OOS) ++
-- UPDATING OF BUFFER ADDRESS
BUF_A(W_ADR) <= W_ADR
-- UPDATING OF BITMAP
IF CELL(M) = 0
    -- CASE OF UNICAST CELL
    BMAP(W_ADR) <= BITMAP(CELL(UC-TAG))
ELSE
    -- CASE OF MULTICAST CELL
    BMAP(W_ADR) <= CELL(MC-TAG)
ENDIF
INI_CNT: INITIAL ADDRESS GENERATION COUNTER
MAX: BUFFER LENGTH IN USE
W_ADR: WRITE ADDRESS
EMP_S_PNT: FREE ADDRESS FIFO START POINTER
LINK(x): ADDRESS LINKED TO ADDRESS x
CNT_L(x): INDIVIDUAL BUFFER QUEUE LENGTH OF BUFFER x
CNT_M(x): MULTICAST BUFFER QUEUE LENGTH OF OoS CLASS x
CNT_S(x): COMMON BUFFER QUEUE LENGTH OF OoS CLASS x
S_PNT(x): START POINTER OF BUFFER x
E_PNT(x): END POINTER OF BUFFER x
BUF_A(x): BUFFER ADDRESS OF ADDRESS x
CELL(x): VALUE OF HEADER x OF INPUT CELL
BMAP(x): ROUTING BIT (BITMAP) OF ADDRESS x
BITMAP(x): CONVERT CODE x INTO BITMAP
```


FIG. 28

MC_TOP_E: MULTICAST HEAD ADDRESS IS EFFECTIVE
 MC_TOP: MULTICAST HEAD ADDRESS
 MC_QOS: QoS NUMBER OF MULTICAST CELL
 MC_ADD: MULTICAST ADDED ADDRESS
 MC_BMAP: MULTICAST REMAINING ROUTING BIT (BITMAP)
 BMAP(x): ROUTING BIT (BITMAP) OF ADDRESS x
 S_PNT(x): START POINTER OF BUFFER x
 E_PNT(x): END POINTER OF BUFFER x
 EMP_S_PNT: FREE ADDRESS FIFO START POINTER
 LINK(x): ADDRESS LINKED TO ADDRESS x
 CNT_M(x): MULTICAST BUFFER QUEUE LENGTH OF QoS CLASS x
 CNT_S(x): COMMON BUFFER QUEUE LENGTH OF QoS CLASS x
 INI_CNT: INITIAL ADDRESS GENERATION COUNTER
 MAX: BUFFER LENGTH IN USE
 ADP_VAL: FREE ADDRESS IS EFFECTIVE




FIG.32




FIG.33

```

-- ACQUISITION OF ADDRESS
  BUF = LINE x 4 + QoS
  R_ADR = S_PNT(BUF)
  BUF_ADR = BUF_A(ADR)

-- ACQUISITION OF BITMAP
  BMAP = BMAP(BUF_ADR)

-- JUDGING OF READ-OUT ADDRESS RETURN
  IF R_ADR < > BUF_ADR
    LINK(EMP_E_PNT) = R_ADR
    EMP_E_PNT = R_ADR

-- UPDATING OF COUNTER
  CNT_S(QoS)
  END IF

-- UPDATING OF POINTER
  S_PNT(BUF) = LINK(S_PNT(BUF))

-- UPDATING OF BITMAP
  BMAP = BITMAP(LINE)
  IF BMAP = 0
    --- JUDGING OF END OF READING

-- RETURN OF BUFFER ADDRESS
  LINK(EMP_E_PNT) = BUF_ADR
  EMP_E_PNT = BUF_ADR

-- UPDATING OF COUNTER
  CNT_S(QoS)
  END IF

-- UPDATING OF COUNTER
  CNT_L(BUF)

```

R_ADR: READ-OUT ADDRESS
 S_PNT(x): START POINTER OF BUFFER x
 BUF: READ-OUT BUFFER NUMBER
 LINE: READ-OUT OUTGOING ROUTE NUMBER
 QoS: READ-OUT QoS NUMBER
 BUF_A(x): BUFFER ADDRESS OF ADDRESS x
 BUF_ADR: BUFFER ADDRESS CORRESPONDING TO READ-OUT ADDRESS x
 BMAP(x): ROUTING BIT (BITMAP) OF ADDRESS x
 BMAP: ROUTING BIT (BITMAP) CORRESPONDING TO BUFFER ADDRESS
 LINK(x): ADDRESS LINKED TO ADDRESS x
 EMP_E_PNT: FREE ADDRESS FIFO END POINTER
 CNT_S(x): COMMON BUFFER QUEUE LENGTH OF QoS CLASS x
 CNT_L(x): INDIVIDUAL BUFFER QUEUE LENGTH OF QoS CLASS x
 BITMAP(x): CONVERT CODE x INTO BITMAP

FIG.34







FIG. 35

FIG.35



- ACQUIRE READ-OUT ADDRESS 10 FROM HEAD OF ADDRESS FIFO
- ACQUIRE BUFFER ADDRESS 10 FROM ADDRESS 10 OF BUF_A
- READ CELL FROM ADDRESS 10 OF CELL BUFFER
- NO RETURN TO FREE ADDRESS FIFO BECAUSE OF READ-OUT ADDRESS BEING COINCIDENT WITH BUFFER ADDRESS
- RESET BIT 3 OF BMAP ADDRESS 10. =>ALLO IS NOT ESTABLISHED, AND BUFFER ADDRESS 10 IS NOT THEREFORE RETURNED



READ-OUT INDICATION
-OUTGOING ROUTE 3
-QoS1





FIG.36

ADDRESS FIFO
OUTGOING ROUTE 0
QoS1


| | |
|----|---|
| 20 | 1 |
|----|---|

FREE ADDRESS FIFO

| | |
|---|---|
| 2 | 5 |
|---|---|



- ACQUIRE READ-OUT ADDRESS 1 FROM HEAD OF ADDRESS FIFO
- ACQUIRE BUFFER ADDRESS 10 FROM ADDRESS 1 OF BUF_A
- READ CELL FROM ADDRESS 10 OF CELL BUFFER
- RETURN ADDRESS 1 TO FREE ADDRESS FIFO BECAUSE OF READ-OUT ADDRESS BEING NON-COINCIDENT WITH BUFFER ADDRESS
- RESET BIT 0 OF BMAP ADDRESS 10. =>ALLO IS NOT ESTABLISHED, AND BUFFER ADDRESS 10 IS NOT THEREFORE RETURNED



READ-OUT INDICATION
-OUTGOING ROUTE 0
-QoS1





FIG.37






FIG.39




FIG.40




FIG.41




FIG.42






FIG.43





43




FIG. 46




FIG.47




FIG.49




FIG.51




FIG. 4

NOTIFICATION OF ARRIVAL LINE
AND QoS CLASS (TO SCHEDULER)

INDICATION OF READ-OUT LINE (FROM SCHEDULER)





FIG. 8






FIG.12




FIG.14




FIG. 15




FIG. 16




FIG.17




FIG. 18 is a block diagram of a system for dividing a target RAM in an established way.

FIG. 18




FIG.19




FIG.20




FIG. 22

